

Kajeet SmartSpot® V400

Quick Start Guide



POWER BUTTON: Powers the Kajeet SmartSpot on and off and wakes the device from sleep. This button is also used as the 'OK' button when browsing through the menu.

MENU BUTTON: Used to pull up the menu and switch between menu options.

SMARTSPOT CHARGING PORT: The AC charger supplied with your SmartSpot connects here.

STATUS DISPLAY: Provides connection and battery status, network signal, and Wi-Fi network information.

The Kajeet SmartSpot® is a portable Wi-Fi hotspot that extends the school day by providing the fastest, filtered broadband access anywhere.



www.kajeet.com

SMARTSPOT_V400_200508

Accessing

Your Kajeet SmartSpot Wi-Fi Name and Password

1. Power on the device by holding the power button until you see 'WELCOME' on the screen.
2. When on the home screen, press the menu button to bring up the device menu.
3. Press the menu button once more to get to "2.4 GHz WIFI INFO". Press power button to select.
4. Note the Wi-Fi network name next to the Wi-Fi symbol (ex. Kajeet SmartSpot #####).
5. On the back of the device, note the Wi-Fi password on the sticker.

IF STICKER IS MISSING FROM DEVICE: Your default Wi-Fi password is made up of the word "smartspot" and the last 4 digits of the device's serial number (IMEI). For example, if the IMEI of your device is 356640011224567, then your Wi-Fi password is: **smartspot4567**

Connecting

To Your Kajeet SmartSpot

1. Make sure the Kajeet SmartSpot is powered on. If the device has gone to sleep, press the power button once to wake it up.
2. On your computer, tablet, mobile phone, or other Wi-Fi enabled device, select the Kajeet SmartSpot Wi-Fi network name (ex. Kajeet SmartSpot #####) from the list of available Wi-Fi networks on your device.
3. When prompted for password, enter the Wi-Fi password from step 5 under "Accessing Your Kajeet SmartSpot Wi-Fi Name and Password" (ex. smartspot#####).
4. You should now be connected to the internet

To view your device's status and data usage, visit kajeet.com/status. For support with your device please contact your school or district technology department.

Guide for Students & Parents

WHAT DOES THE SMARTSPOT® DO?

The Kajeet SmartSpot is a portable Wi-Fi hotspot device that provides your child with safe, education-only Internet access wherever there is cellular coverage.

Your child will be able to access the Internet outside the classroom to complete homework, read online materials, collaborate with classmates, or connect with teachers. Your child will not be able to access any entertainment, adult, or inappropriate content.

HOW ARE THE SMARTSPOTS FILTERED?

The devices are filtered with Kajeet Education Broadband™. These cloud-based filters provide your child with safe, education-only Internet access.

WHAT INFORMATION CAN THE SCHOOL TRACK ON THIS DEVICE?

The SmartSpot devices are provided by your school for your children to access the Internet for **educational purposes only**. No private information (such as student name, login information, account numbers, etc.) is collected or retained, however the school will have the capability to track device usage trends such as what sites are visited and data usage.



WHY CAN'T I GET TO CERTAIN WEBSITES?

Kajeet filters out non-educational sites. Your school district may also be filtering out social and streaming media to keep students focused on school work. Kajeet Education Broadband adds another level of security with filtering policies that block harmful content such as websites containing malware, viruses, proxies, and phishing.

WHAT IF MY SMARTSPOT DOESN'T WORK? WHO SHOULD I CONTACT?

If your SmartSpot is not working properly, please contact your teacher or school technology advisor.

STUDENT INTERNET SAFETY TIPS

- 1 Never respond to harassing or rude texts, messages, and e-mails.
- 2 Never give out your password to anyone other than your parent or guardian.
- 3 If you wouldn't say something to another person's face, don't post it online!
- 4 Think before posting your photos. DO NOT post or send semi-nude or nude pictures of yourself or anyone else!
- 5 Never post your personal information such as cell phone number, address, or the name of your school online.
- 6 Be aware that information you give out through any website could put you at risk of bullying or other types of victimization.
- 7 Never agree to meet in person with anyone you first "met" online.
- 8 Be aware that posting information about your friends puts them at risk.

CONTACT AN EDUCATION BROADBAND SPECIALIST TODAY.

Email: sales@kajeet.net Call: 240-482-3500 www.kajeet.com

Copyright 2017, Kajeet, Inc. All rights Reserved.



Loaner Device Agreement

Roanoke County Public Schools LOANER DEVICE AGREEMENT

As a guardian or student I agree to the following statements related to a loaned device for educational use at home.

I have already agreed to follow the Roanoke County Public Schools Acceptable Use Policy.

1. I understand the device(s) is/are the property of Roanoke County Public Schools and the district retains all rights to the hardware and software.
2. I understand I am completely responsible for the devices while checked out.
3. I agree to follow all Roanoke County Public Schools regulations and policies governing the use of the device as well as all applicable State and Federal laws including copyright and intellectual property law pertaining to software and information.
4. I agree not to remove or alter any Roanoke County Public Schools identification labels attached to or displayed on the device(s), or to change identification within the device(s).
5. I agree to keep the device and district information safe and secure. (i.e. Don't leave the device(s) in open view in your locked car, in areas of extreme temperature or humidity.)
6. I agree to report theft, loss, or damage to the device to the school library or school office immediately and to the police in the case of theft.
7. I agree to deliver the device promptly to designated location for technical inspection, to verify inventory, or for other reasons when requested.
8. I agree to return the equipment at the end of the loan period to the assigned location or when my family moves out of the district.
9. I agree all repair work will be completed by the district.
10. I agree the only support the district will provide are instructions on any required setup.
11. I agree the district cannot guarantee wireless coverage.
12. I agree excessive use of the Internet, use beyond instructional purposes, or repair beyond normal wear may reduce or eliminate my access to a loaner device.
13. I understand I am responsible for monitoring and guiding my child(ren)'s activity at home.

I have read and understand all terms of the agreement.

I have discussed the agreement with my child(ren) and will support the school in guiding my child(ren) in using the device at home as an educational tool.

Parent or Guardian Signature

Date

RCPS Asset Number

Student Signature

Date